

Where ingenuity takes off

Nano-Clear Coating NCI UTC Test Results

K. YEE 02/25/2015




Nano-Clear NCI - Test Panels








Nano-Clear NCI After Adhesion Test








Nano-Clear NCI - 2 Coats After Adhesion Testing







Nano-Clear NCI - 3 Coats After Adhesion Testing







Nano-Clear NCI After Hammer Testing










Nano-Clear NCI – 2 Coats After Hammer Test










Nano-Clear NCI – 3 Coats After Hammer Test









Nano-Clear NCI – 2 Coats After Sand Blasting







Nano-Clear NCI – 3 Coats After Sand Blasting



Test setup:

In the Westford machine shop, with the Empire Sand Blaster, @ 100 psi, using Al2O3 Brown sand, 80 grit size (McMaster Carr). Stand-off distance is about 20 inches from the nozzle-to-sample. Blast time is 30 seconds





Nano-Clear NCI Blasted and 5 Washing Cycles



